



SECTION FOR HYDRANTS AND WATER METER SERVICE

NOTES:

1. MEGALUGS BETWEEN VALVE AND HYDRANT MUST BE USED ALONG WITH CONCRETE BLOCKING.
2. WHEN THE METER AND CLEANOUT ARE LOCATED AT THE IDEAL LOCATION, SIDE BY SIDE AT THE R/W LINE. THE SEPARATION BETWEEN THE WATER METER AND THE SEWER CLEANOUT SHALL BE 18" MINIMUM BETWEEN THE CLOSEST EDGE OF THE WATER METER AND THE CENTER OF THE CLEANOUT PIPE.
3. THE BURY LINE ON THE HYDRANT SHOULD BE AS CLOSE AS FEASIBLE TO 2.5" ABOVE THE TOP OF CURB GRADE.

SHEET 1 OF 3
DATE: 3/1/14

CITY OF REIDSVILLE

HOUSE CONNECTION AND HYDRANT SETTING DETAIL

STD. NO.	REV.
101	